



INSTALLATION GUIDE · GUÍA DE INSTALACIÓN

ALUMINUM SOFFIT

According to NOA No. 23-1208.15 · Miami-Dade County | Conforme al NOA No. 23-1208.15 · Condado de Miami-Dade

ESPAÑOL

1 INSTALACIÓN DE J-CHANNEL

1. Instalar J-channels en todo el perímetro e instalar furring strips si es necesario.
2. Deben estar nivelados y alineados.
3. Fijación cada 12 pulgadas como máximo.

2 CORTE DE PANELES

1. Medir distancia entre J-channels opuestos.
2. Cortar paneles dejando tolerancia de 1/8" a 1/4" para expansión.

3 INSTALACIÓN DEL SOFFIT

1. Insertar un extremo del panel dentro del J-channel.
2. Fijar mecánicamente cada 12 pulgadas.
3. Mantener alineación correcta y holgura para expansión.

4 INSPECCIÓN FINAL

1. Verificar correcta fijación y alineación de todos los paneles.
2. Confirmar que no existan tornillos flojos.
3. Confirmar cumplimiento total con el NOA.

ENGLISH

1 J-CHANNEL INSTALLATION

1. Install J-channel around the perimeter and install furring strips if necessary.
2. They must be level and aligned.
3. Fixation every 12 inches maximum.

2 PANEL CUTTING

1. Measure distance between opposite channels.
2. Cut panels leaving 1/8" to 1/4" tolerance for expansion.

3 INSTALLATION OF SOFFIT PANELS

1. Insert one end of the panel into the J-channel.
2. Mechanically fasten every 12 inches.
3. Maintain correct alignment and clearance for expansion.

4 FINAL INSPECTION

1. Verify the correct attachment and alignment of all panels.
2. Confirm that there are no loose screws.
3. Confirm full compliance with the NOA.

NOTA / NOTE: Documento técnico preparado conforme a los requisitos del NOA No. 23-1208.15 de Miami-Dade County. Technical document prepared in accordance with the requirements of Miami-Dade County NOA No. 23-1208.15. La instalación debe realizarse siguiendo el NOA oficial vigente. / Installation must follow the current official NOA.